

Attention pilots seeking increased control precision: Don't forget to increase the spring tension in your InterLink transmitter. If that isn't enough, consider installing Century Spring Corp Heavier Springs for Spektrum Transmitters [Link](#) Crescent Brand Miniature Cutters & Needle-Nose Pliers Set Item S2KS5 work great to install new springs [Link](#)

## Ratcheted Throttle – Smooth Throttle Adjustment

### Ratchet

1. Locate the Throttle Strap adjustment screws on both gimbals. The ratchet set screw engages a serrated section on the gimbal for a ratcheted throttle, while the tension set screw engages a strap for smooth tension on the gimbal.
2. To engage the throttle ratchet turn the ratchet set screw clockwise until the ratchet engages.
3. To disengage the throttle ratchet turn the screw counter clockwise until the gimbal moves freely.

### Smooth Tension

1. To engage the throttle tension, turn the Tension set screw clockwise until the Tension engages.
2. To disengage the throttle Tension turn the screw counter clockwise until the gimbal moves freely.

## Adjust Stick Tension

Turn the screws clockwise a small amount using a small Phillips screwdriver to tighten the stick tension and counter clockwise to loosen.

